

---

# Triax

---

## TD 110 dish


---




Assembly and mounting instructions  
Montageanleitung  
Notice de montage  
Montagevejledning




# 1




# 2




# 3




4




5




6




7



8




**Astra**  
Satellite Position 28.2° East




Az 130° 135° 140° 145° 150° 155°

**Astra**  
Satellite Position 19.2° East




Az 145° 150° 155° 160° 165° 170° 175°

**Eutelsat - Hot Bird**  
Satellite Position 13° East




Scale (Az) 150° 155° 160° 165° 170° 175° 180° 185°

**Eutelsat**  
Satellite Position 10° East




Scale (Az) 155° 160° 165° 170° 175° 180° 185° 190°

**Sirius**  
Satellite Position 5° East




Az 185° 190° 195° 200° 205°

**Eutelsat - Thor**  
Satellite Position 1° West




Scale (Az) 195° 200° 205° 210° 215°

**Eutelsat - Telecom 2A - 2B**  
Satellite Position 8°/5° West



Scale (Az) 180° 185° 190° 195° 200° 205° 210°

**Hispasat**  
Satellite Position 30° West



Scale (Az) 210° 215° 220° 225° 230° 235°

